



OIL SPILL EATER INTERNATIONAL, CORP.

13127 Chandler Drive
Dallas, Texas 75243
(972) 669-3390
(972) 644-8359 Fax
admirallively@msn.com

CLEANUP PROCEDURES



13127 Chandler Drive
Dallas, Texas 75243
(972) 669-3390
(972) 644-8359 Fax
admirallively@msn.com

April 30, 2002

OIL SPILL EATER II PROCEDURE FOR OIL SPILL CLEANUP

GENERAL INFORMATION

It takes approximately 2 to 24 hours for OIL SPILL EATER II to penetrate the molecular wall of fresh crude oil. It takes OIL SPILL EATER II approximately 3 to 15 minutes to penetrate the molecular wall of light end petroleum or gasoline.

However, once you spray OIL SPILL EATER II on the oil, it attaches itself and will eventually engulf the oil regardless of where the oil or light petroleum may spread on ocean waters or on rivers and streams.

Additionally, once sprayed with OIL SPILL EATER II, the oil cannot attach itself to the shoreline, to rocks or to any equipment in its path.

If OIL SPILL EATER II is to be used on ocean spills or on Intertidal Zones, mix product with ocean water.

If OIL SPILL EATER II is to be used on lakes, rivers, streams, ponds or on land, mix with water from a lake, river, stream or pond.

If you are performing a cleanup, **MAKE SURE** that the water used to mix with OSEII and the water used to keep area saturated is the type of water normally associated with that area. If you use fresh water in an area normally contacted with salt water or vice versa, these are different types of bacteria and competition could occur. Competition will slow the bioremediation until the area re-stabilizes.

NOTE: *Never mix tap (faucet) water and OIL SPILL EATER II (IF POSSIBLE).
The chlorine in the tap (faucet) water slows bacterial enhancement.*

These *Procedures and Application Instructions* cover Heavy End and Light End Hydrocarbons. The OSEI Corporation defines Light End Hydrocarbons as: BETX, gasoline and light solvents. Heavy End Hydrocarbons are crude oil, halogenated hydrocarbons, heavy



13127 Chandler Drive
Dallas, Texas 75243
(972) 669-3390
(972) 644-8359 Fax
admirallively@msn.com

OIL SPILL EATER II

PROCEDURE FOR CLEANUP OF BIRDS AND MAMMALS

Dilution for application to animals or birds should be one (1) part "Oil Spill Eater II" concentrate to sixty (60) parts water. Feathered animals should not be released after cleaning until natural oils have been restored.

NOTE: *It is OKAY to mix with tap water; however, sterile water, ocean water or fresh water is preferable.*

A handwritten signature in cursive script, appearing to read 'Steven R. Pedigo'.

Steven R. Pedigo
Chairman

SRP/eem